



1. SEE ARCHITECTURAL PLANS, SECTIONS AND ELEVATIONS FOR EXACT EQUIPMENT AND DEVICE LOCATIONS.
2. SEE ARCHITECTURAL PLANS FOR LOCATIONS OF SOUND, SMOKE AND FIRE RATED WALLS.
3. REFER TO MECHANICAL DRAWINGS FOR FIRE/SMOKE DAMPER LOCATIONS. PROVIDE FIRE ALARM MONITORING POINT FOR EACH FIRE/SMOKE DAMPER.
4. CONTRACTOR SHALL OBTAIN THE FINAL OWNER APPROVED HILLROM NURSE CALL SHOP DRAWINGS PRIOR TO POUR-IN.

- 1 RECESSED FLOOR BOX. UTILIZE BOX FOR BOTH POWER AND TELE/DATA. SEE DRAWING E3.01. COORDINATE EXACT LOCATION WITH ARCHITECT PRIOR TO ROUGH-IN.
- 2 PYXS CONNECTION.
- 3 COPIER CONNECTION.
- 4 DATA OUTLETS LOCATED IN EQUIPMENT CLOSET. SEE ARCHITECTURAL INTERIOR ELEVATIONS FOR EXACT MOUNTING HEIGHT.
- 5 PROVIDE (2) 3.5"x3.5" SQUARE EZ PATH DEVICES OR APPROVED.
- 6 PANIC BUTTON CONNECTION. PROVIDE 4" SQUARE BOX.
- 7 ROUTE 3/4" CONDUIT TO IS ROOM 1087. WALL MOUNT AT 48" AFF.
- 8 ROUTE 1" CONDUIT TO IS ROOM 1087 FOR ELEVATOR CAB PHONE.
- 9 PROVIDE (4) 3.5"x3.5" SQUARE EZ PATH DEVICES OR APPROVED.
- 10 TIME CARD CONNECTION VERIFY LOCATION WITH ARCHITECT PRIOR TO ROUGH-IN.
- 11 PROVIDE FIRE ALARM TERMINATION CABINET IN LOW VOLTAGE ROOM AS SHOWN.



0	100% CD SET 9/26/08
1	CCD #4 12/17/08

FIRST FLOOR  
PLAN - SOUTH  
SYSTEMS

E4  
01

N: \B13608\CADD-05\400\_E4-01.DWG DEC 18, 2008 - 11:42:39 AM BY: JLUO