



1. SEE ARCHITECTURAL PLANS, SECTIONS AND ELEVATIONS FOR EXACT EQUIPMENT AND DEVICE LOCATIONS.
2. SEE ARCHITECTURAL PLANS FOR LOCATIONS OF SOUND, SMOKE AND FIRE RATED WALLS.
3. REFER TO MECHANICAL DRAWINGS FOR FIRE/SMOKE DAMPER LOCATIONS. PROVIDE FIRE ALARM MONITORING POINT FOR EACH FIRE/SMOKE DAMPER.
4. CONTRACTOR SHALL OBTAIN THE FINAL OWNER APPROVED HILLROM NURSE CALL SHOP DRAWINGS PRIOR TO ROUGH-IN.

- ▶ NOT USED.
- ▶ PANIC BUTTON CONNECTION.
- ▶ PHYSIX CONNECTION.
- ▶ PROVIDE (2) 3.5"x3.5" SQUARE EZ PATH DEVICES OR APPROVED.
- ▶ PROVIDE (4) 3.5"x3.5" SQUARE EZ PATH DEVICES OR APPROVED.
- ▶ PROVIDE (1) 3.5"x3.5" SQUARE EZ PATH DEVICES OR APPROVED.
- ▶ NOT USED.
- ▶ TIME/CLOCK CONNECTION VERIFY LOCATION WITH ARCHITECT PRIOR TO ROUGH-IN.
- ▶ CENSES BOARD CONNECTION. VERIFY EXACT LOCATION WITH ARCHITECT PRIOR TO ROUGH-IN.
- ▶ PROVIDE (4) 3.5" x 3.5" SQUARE EZ PATH DEVICES THROUGH THIRD FLOOR TO FOURTH FLOOR IS ROOM. PROVIDE ALL FLOOR MOUNTING ACCESSORIES TO PROVIDE A COMPLETE SYSTEM.
- ▶ PROVIDE FIRE ALARM TERMINATION CABINET IN LOW VOLTAGE ROOM AS SHOWN.