



KEY NOTES:

- ① FURNISH AND INSTALL (2) 4"x8" BACKBOARD. PROVIDE #6 GRD TO GROUND BUS BAR.
- ② PROVIDE 2"C.O. TO ROOF FOR PHOTOVOLTAIC SYSTEM.
- ③ FURNISH AND INSTALL 10"x8" GROUND BUS BAR AND PROVIDE #4 GRD TO MAIN GROUND.

