


**SHERWIN  
WILLIAMS®**

As of 8/8/2018, Complies with:			
OTC	Yes	LEED® 09 NC CI	Yes
OTC Phase II	Yes	LEED® 09 CS	Yes
SCAQMD	Yes	LEED® v4 Emissions	No
CARB	Yes	LEED®v4 VOC	Yes
CARB SCM 2007	Yes		
Canada	Yes	MPI	

**SUPERPAINT®**
**Interior Latex Semi-Gloss**

A88W01150 Hi-Refl White

A88W01251 Extra White

A88W01153 Deep Base

A88T01154 Ultradeep Base

### CHARACTERISTICS

**SuperPaint Interior Latex Semi-Gloss** is for use on previously painted, bare or primed wallboard and wood, and primed plaster, masonry and metal. SuperPaint paint and primer in one provides fast & easy application, while offering excellent hide and durability.

**Color:** Most colors  
To optimize hide and color development, always use the recommended P-Shadow primer

**Coverage:** 350 - 400 sq ft/gal  
@ 4 mils wet; 1.5 mils dry

**Drying Time, @ 77°F, 50% RH:**

Touch: 1 hour

Recoat: 4 hours

Drying and recoat times are temperature, humidity, and film thickness dependent

**Finish:** 25-35 units @ 60°

**Tinting with CCE:**

Base	oz/gal	Strength
High Refl White	0-7	Sher-Color
Extra White	0-6	Sher-Color
Deep Base	4-12	Sher-Color
Ultradeep Base	10-14	Sher-Color

**Extra White A88W01251**

(may vary by base)

**VOC (less exempt solvents):**

<50 g/L; 0.42 lb/gal  
As per 40 CFR 59.406

**Volume Solids:** 37 ± 2%

**Weight Solids:** 49 ± 2%

**Weight per Gallon:** 10.35 lb

**Flash Point:** N/A

**Vehicle Type:** Vinyl Acrylic

### SPECIFICATIONS

**SuperPaint Interior Latex can be used directly over existing coatings, or bare drywall, plaster (cured with a pH of less than 9), masonry (cured with a pH of less than 9) and non-bleeding wood.**

#### **Drywall**

Self-prime using 2 cts. of SuperPaint Interior Latex

or

1 ct. Premium Wall & Wood Primer

2 cts. SuperPaint Interior Latex

#### **Masonry / Block**

(can be filled to provide a smooth surface or primed if it is a high pH substrate)

1 ct. Loxon Acrylic Block Surfer

or

1 ct. Loxon Concrete & Masonry Primer/Sealer

2 cts. SuperPaint Interior Latex

#### **Plaster**

Self-prime using 2 cts. of SuperPaint Interior Latex

or

1 ct. Premium Wall & Wood Primer

2 cts. SuperPaint Interior Latex

#### **Wood**

Self-prime using 2 cts. of SuperPaint Interior Latex

or

1 ct. Premium Wall & Wood Primer

2 cts. SuperPaint Interior Latex

If the wood has bleeding (such as tannin or knot-holes), prime with Multi-Surface Primer.

Other primers may be appropriate.

When repainting involves a drastic color change, a coat of primer will improve the hiding performance of the topcoat color.

### SURFACE PREPARATION

**WARNING!** Removal of old paint by sanding, scraping or other means may generate dust or fumes that contain lead. Exposure to lead dust or fumes may cause brain damage or other adverse health effects, especially in children or pregnant women. Controlling exposure to lead or other hazardous substances requires the use of proper protective equipment, such as a properly fitted respirator (NIOSH approved) and proper containment and cleanup. For more information, call the National Lead Information Center at **1-800-424-LEAD** (in US) or contact your local health authority.

Remove all surface contamination by washing with an appropriate cleaner, rinse thoroughly and allow to dry. Existing peeled or checked paint should be scraped and sanded to a sound surface. Glossy surfaces should be sanded dull. Stains from water, smoke, ink, pencil, grease, etc. should be sealed with the appropriate primer/sealer. Recognize that any surface preparation short of total removal of the old coating may compromise the service length of the system.

#### **Drywall**

Fill cracks and holes with patching paste/spackle and sand smooth. Joint compounds must be cured and sanded smooth. Remove all sanding dust.

#### **Masonry, Concrete, Cement, Block**

All new surfaces must be cured according to the supplier's recommendations—usually about 30 days. Remove all form release and curing agents. Rough surfaces can be filled to provide a smooth surface. If painting cannot wait 30 days, allow the surface to cure 7 days and prime the surface with Loxon Concrete & Masonry Primer/Sealer.



# SUPERPAINT<sup>®</sup>

## Interior Latex Semi-Gloss

A88W01150 Hi-Refl White  
 A88W01251 Extra White  
 A88W01153 Deep Base  
 A88T01154 Ultradeep Base

<u><b>SURFACE PREPARATION</b></u>	<u><b>APPLICATION</b></u>	<u><b>CAUTIONS</b></u>
<p><b>Plaster</b>          Bare plaster must be cured and hard. Textured, soft, porous, or powdery plaster should be treated with a solution of 1 pint household vinegar to 1 gallon of water. Repeat until the surface is hard, rinse with clear water and allow to dry.</p> <p><b>Wood</b>          Sand any exposed wood to a fresh surface. Patch all holes and imperfections with a wood filler or putty and sand smooth.</p> <p><b>Mildew</b>          Prior to attempting to remove mildew, it is always recommended to test any cleaner on a small, inconspicuous area prior to use. Bleach and bleaching type cleaners may damage or discolor existing paint films. Bleach alternative cleaning solutions may be advised.          Mildew may be removed before painting by washing with a solution of 1 part liquid bleach and 3 parts water. Apply the solution and scrub the mildewed area. Allow the solution to remain on the surface for 10 minutes. Rinse thoroughly with water and allow the surface to dry before painting. Wear protective eyewear, waterproof gloves, and protective clothing. Quickly wash off any of the mixture that comes in contact with your skin. Do not add detergents or ammonia to the bleach/water solution.</p> <p><b>Caulking</b>          Gaps between walls, ceilings, crown moldings, and other interior trim can be filled with the appropriate caulk after priming the surface. Allow proper drying time before application of the finish.</p>	<p>Apply at temperatures above 50°F. No reduction needed.</p> <p><b>Brush</b>          Use a nylon/polyester brush.</p> <p><b>Roller</b>          Use a 3/8" - 3/4" nap synthetic cover.</p> <p><b>Spray—Airless</b>          Pressure .....2000 psi          Tip......017"-.021"</p>	<p>For interior use only.          Protect from freezing.          Non-photochemically reactive.</p> <p>Before using, carefully read <b>CAUTIONS</b> on label.</p> <p>HOTW 8/8/2018 A88W01251 04 35          KOR, FRC,SP, Viet</p> <p><u><b>CLEANUP INFORMATION</b></u></p> <p>Clean spills, spatters, hands and tools immediately after use with soap and warm water. After cleaning, flush spray equipment with compliant cleanup solvent to prevent rusting of the equipment. Follow manufacturer's safety recommendations when using solvents.</p> <p>The information and recommendations set forth in this Product Data Sheet are based upon tests conducted by or on behalf of The Sherwin-Williams Company. Such information and recommendations set forth herein are subject to change and pertain to the product offered at the time of publication. Consult your Sherwin-Williams representative or visit <a href="http://www.paintdocs.com">www.paintdocs.com</a> to obtain the most current version of the PDS and/or an SDS.</p>